

DETERGENTE PULITORE FUGHE

CLEANER FOR JOINTS

DESCRIPTION:

DETERGENTE PULITORE FUGHE is a degreaser, very effective against dirt, even old layers encrusted into floor joints. The product is fast and effective.

CAN BE APPLIED WITH:



USE:

ADVANTAGES:

- Excellent cleaning power
- Versatile
- Does not etch neither polished marbles nor sensible surfaces
- Does not etch joints

WHERE TO APPLY:

Cotto, terracotta tiles, marbles, slates, granites, natural stones, travertine, porcelain stoneware, ceramic and any type of surface which is not too much sensitive towards alkaline substances.

COVERAGE:

10 to 20 sq.m/lt.

Use the product diluted in water at 50%. Apply to the surface with a suitable pad and scrubbing brush (depending on the dirt and on the material, choose a more or less effectual pad) or if possible, even a mono-brush in order to achieve the maximum result, focusing on the joints. After cleaning for a few minutes, vacuum up the residues of washing with a wet vacuum or with the traditional method. Rinse well with clean water, until every residue will have been removed. In case of stubborn dirt, use the product undiluted.

MAINTENANCE:

For everyday cleaning, use DETERGENTE IGIENIZZANTE PAVIMENTI UNIVERSALE or a revitalizing product special for the type of material.

PRECAUTIONS

Never use for wood or linoleum. Do not allow the product for a long time in contact with surfaces.



TECHNICAL DATA:

Aspect	: Liquid
Colour	: Amber
Odour	: Typical
pH	: 12.5 ± 0.5
Biodegradability	: >90%
Specific Gravity (20°C)	: 1050 ± 10 g/l.

STORAGE:	Keep the container closed and in a cool dry place.
SHELF LIFE:	36 months in the original sealed packing and kept in a cool and dry place.
PACKAGING:	500 ml. sprayer (12 pcs per carton)
AVOID:	Never use the product in combination with other chemicals

SAFETY:



- R34 : Causes burns
- S2 : Keep out of the reach of children
- S24 : Avoid contact with skin
- S25 : Avoid contact with eyes
- S26 : In case of contact with eyes, wash immediately with plenty of water and call for a doctor

THOUGH THE INFORMATION ON THIS SHEET ARE THE RESULTS BOTH OF OUR RESEARCH AND OPERATIONAL TECHNICAL EXPERIENCE, THEY CANNOT BE CONSIDERED UNDERTAKING OR INVOLVE OUR RESPONSIBILITY AS THE CONDITIONS REQUIRED FOR THE APPLICATION CANNOT BE SUPERVISED BY US. FABER CHIMICA S.R.L. DOES NOT PROVIDE ANY WARRANTY, EITHER EXPRESS OR IMPLIED AND DOES NOT ASSUME ANY RESPONSIBILITY CONCERNING THE USE OF THESE DATA AND SUGGESTIONS.

Rev.n. 0.0

Date: 12/11/2013